

MONGOOSE REMOTE CONTROLS AND REPLACEMENT CASES

NOTE: When ordering fixed code remotes, please provide the code number found inside an existing remote or inside the control module.



Superseded by →



M60

**M60/Phase
MRC60**

Case: 242060

Case: 242060



Superseded by →



MX750

MRC750

Case: 242035

M80

MRC80

Case: 242080



MCA500

MRC500

N/A



Superseded By ----→



MX200/MX40/AA660

MRC200

N/A

MX40MkII

MRC200

Case: 242200



All can use waterproof as option →



Waterproof remote

MX200/M20/M24/MX40

MRC200

Case: 242024

MCL2000

MRC200W

Case: 242200W



Whilst looking similar, they use different PCB & coding system. Quote code number found on white label inside.

M400 / M450

MRC400/MRC450NZ

Case: 242021



not available
out of production.
No replacements

MX1/5/220/AA600

MRC220

Case: 242220



MX120

MRC120

Case: 242120



MX10

MRC10

Case: 242010



M1200MkI

MRC1200/950

Case: use 242030



VP COMMODORE

GMH1

Case: 242013



VN COMMODORE

GMH2

Case: 242012



M450MkI/M950

Single or two button

Case: 242004



M550/M1200

MRC1202

Case: 242030



Superseded by →



M560

FIXED CODE
CO
DE
LEARNING
ING



- a) Disarm or use PIN override – open door – LEAVE OPEN
- b) Ignition ON/OFF 3 times – siren chirps
- c) Press arm button on first remote (siren chirps)
- d) Press arm button on any other remote (siren chirps)
- e) Leave for 10 seconds to complete programming



- a) Disarm or use override
- b) Ignition ON and press override button for 5 seconds (siren fast chirps)
- d) Press arm button on first remote (siren chirps)
- e) Press arm button on any other remote (siren chirps)
- f) Turn ignition OFF



- a) Disarm or use override
- b) Ignition ON and press override button 4 times and hold down on 4th press (siren chirps after 3rd press)
- d) Press arm button on first remote (siren chirps)
- e) Press arm button on any other remote (siren chirps)
- f) Release the override button and turn ignition OFF



- a) Disarm or use override
- b) With door closed, turn ignition ON, then open close door 5 times (siren chirps)
- d) Press arm button on first remote (siren chirps)
- e) Press arm button on any other remote (siren chirps)
- f) Turn ignition OFF



- a) Gain access to alarm module
- b) Disarm or use override and turn ignition ON
- c) Press programming switch 4 times and hold down on 4th press (siren chirps after 3rd press)
- d) Press arm button on first remote (siren chirps)
- e) Press arm button on any other remote (siren chirps)
- f) Release the switch and turn ignition OFF



- a) Open existing remote or alarm module to read the code number on a white label attached to the main 'chip'
 - b) Otherwise open alarm module or remote and copy cut tracks
- If GM remote and code not available – contact a Holden dealer to obtain code number – giving VIN and chassis numbers