

Remote Control Listing



TP-09 Fixed Code Remote

Suits: TP360R

Replacement Case: N/A
Replacement Battery: GP27A



TP-10 Fixed Code Remote

Suits: TP360R

Replacement Case: N/A
Replacement Battery: CR927 (x2)



TP-21L Fixed Code Duplicating Remote

FIXED CODE MICROCHIP AX5326S

Suits: Most fixed code remotes.
Must have a working remote to duplicate.

Replacement Case: N/A
Replacement Battery: GP23



TP-48 Fixed Code Remote

Suits: BW-120CDL

Replacement Case: N/A
Replacement Battery: GP27A



TX22B Rolling Code Remote

ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: AB950, VAE 315-950
VAE 317-490

Replacement Case: TX22C
Replacement Battery: CR1616 (x2)



TX23 Rolling Code Remote

ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: VS120, VS220

Replacement Case: TX23C
Replacement Battery: CR1616 (x2)



TX28GB Rolling Code Remote

ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: AB960, CL1100, CL1600
SS850, SS2950

Replacement Case: TX28CB
Replacement Battery: GP23



TX28GS Rolling Code Remote

ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: AB960, CL1100, CL1600
SS850, SS2950

Replacement Case: TX28CS
Replacement Battery: GP23



VAE 318 TX7S Rolling Code Remote

ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: CL1000

Replacement Case: VAE 318 TX7SC
Replacement Battery: GP27



VAE 318 TX7 Rolling Code Remote

ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: CL1500, CL2000, STAGE 2A
STAGE 4A, STAGE 5M, STAGE 5G

Replacement Case: VAE 318 TX7C
Replacement Battery: GP27



VAE 318 TX8 1 Fixed Code Remote

FIXED CODE MICROCHIP AX5326S

Suits: VAE 318-2300, VAE 317-550

Replacement Case: VAE 318 TX8 1C
Replacement Battery: CR1616 (x2)



VAE 318 TX8 2 Rolling Code Remote

ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: VAE 318-1600, VAE 318-1800
VAE 318-2600, VAE 318-2700
VAE 317-650

Replacement Case: VAE 318 TX8 1C
Replacement Battery: CR1616 (x2)





VAE 318 TX9 1 Fixed Code Remote
FIXED CODE MICROCHIP AX5326S

Suits: VAE 317-480, VAE 317-480/4D
VAE 317-580, VAE 318-120

Replacement Case: VAE 318 TX9C
Replacement Battery: CR1616 (x2)



VAE 318 TX9 2 Rolling Code Remote
ROLLING CODE MICROCHIP HCS200 / HCS300 / HCS301

Suits: VAE 315-800/B2, VAE 315-800P2
VAE 317-490, VAE 317-490/4D
VAE 317-320, VAE 317-370

Replacement Case: VAE 318 TX9C
Replacement Battery: CR1616 (x2)



TX100 Touch Key

Suits: VAE 315-100, VAE 315-120

Replacement Case: N/A
Replacement Battery: N/A



VAE 318 TX1A1 Fixed Code Remote
FIXED CODE MICROCHIP AX5326S

Suits: VAE 318-1000, VAE 318-2000

Replacement Case: N/A
Replacement Battery: CR2025 (x2)
Replacement Remote: TP21L

**** MUST HAVE A WORKING REMOTE ****



VAE 318 TX3 Fixed Code Remote
FIXED CODE MICROCHIP AX5326S

Suits: VAE 318-2300

Replacement Case: N/A
Replacement Battery: CR2025 (x2)
Replacement Remote: VAE 318 TX8 1



VAE 318-TX5 1 Fixed Code Remote
FIXED CODE MICROCHIP AX5326S

Suits: VAE 317-480

Replacement Case: N/A
Replacement Battery: CR2025 (x2)
Replacement Remote: VAE 318 TX9 1

HOW TO IDENTIFY A FIXED CODE REMOTE.



Fixed Code Microchip (18 Legs)



The Fixed Code Microchip will have the following identification
AX5326S

HOW TO IDENTIFY A ROLLING CODE REMOTE.



Rolling Code Microchip (8 Legs)



The Rolling Code Microchip will have the following identification
HCS200 or HCS300 or HCS301

